


let your hair loose

got your curling iron, bobby pins, and hair spray?
 you're ready to do the wave!



get this look!


start →




1 Use a tail comb to separate hair into sections.




2 Leave a section of hair loose at the nape of your neck—this is where you'll start curling.




3 Spray hair with a heat-protecting product.



4 Take a small section of hair at the base of your neck, and using a one-inch barrel curling iron, smooth hair by running the iron down the length of the section.




5 Curl the section (from ends to root) with the curling iron.



6 Slip the curl out of the iron and pin into place.



7 Continue curling and pinning other sections into place.



8 Do this until all of your hair is curled. Spritz with hairspray and wait at least 30 minutes before doing the next styling steps.



9 Unwind curls, starting at the nape of your neck. Continue until all clips have been removed.




10 Brush hair gently using a paddle brush.



11 Using a comb, coax hair into a wave and put a clip below the "crest" of the wave.



12 Continue waving and pinning down the length of your hair.



13 Spritz waves with hairspray and allow it to dry.



14 Remove clips and pin in a pretty barrette.

→ finished!